



Ti300U, Ti400U, Ti401U, Ti480U Thermal Imagers




To download SmartView IR software, visit www.fluke.com/smartview-ir.
要下载 SmartView IR 软件, 请访问 www.fluke.com/smartview-ir。




1 ⓘ




2a ⓘ ⓘ
AF




2b ⓘ ⓘ
MF



3 ⓘ



4 ⓘ



5 ⓘ ⓘ

